



CONVERSION CHART

Surface Feet / Minute

$$\text{SFM} = .26 \times \text{Dia.} \times \text{RPM}$$

Inches Per Minute

$$\text{IPM} = \text{RPM} \times \text{FPR}$$

Material Removal Rate

$$\text{MRR} = \text{WOC} \times \text{DOC} \times \text{IPM}$$

Revolutions Per Minute

$$\text{RPM} = \frac{3.82 \times \text{SFM}}{\text{Dia.}}$$

Feed Per Revolution

$$\text{FPR} = \frac{\text{IPM}}{\text{RPM}}$$

-OR-

$$\text{Eff. Flute} \times \text{Feed Per Flute}$$

Feed Per Tooth

$$\text{FPT} = \frac{\text{FPR}}{\text{No. of Eff. Teeth}}$$

1021 6th STREET · PO BOX 1467 · RACINE, WI 53401

262-634-3381 Fax 262-634-1466

www.machineryfactory.com